



Signs & Markings II



Signs & Markings II

Introduction



Advancing the Future of Public Safety

Introduction to Signs and Markings 2

Welcome to the next step in the certification process. You have passed Signs and Markings level 1 and now ready for the next step. In this level we will go into some more details of a few processes like:

- Sign Fabrication
- Sign Installation
- Pavement markings
- Speed Enforcement Radar Signs
- Changeable Message signs
- Inspection of projects
- Traffic Counts and Left Turn Movements



Manual of Uniform Traffic Control Devices - MUTCD

The MUTCD stands for the Manual on Uniform Traffic Control Devices. It is a document published by the Federal Highway Administration (FHWA) in the United States that provides national standards and guidelines for the design, placement, and maintenance of traffic control devices.

The primary purpose of the MUTCD is to promote uniformity and consistency in traffic control devices across the country. These devices include signs, signals, pavement markings, and other elements used to regulate, warn, and guide road users.

Sign sizes are well documented within the MUTCD. They are determined primarily on the speed of the roadway.

This Manual ensures uniformity across the United States and Canada (MUTCDC).



Sign Sizes based on Roadway Type


Table 2B-1. Regulatory Sign and Plaque Sizes (Sheet 1 of 4)

Sign or Plaque	Sign Designation	Section	Conventional Road		Expressway	Freeway	Minimum	Oversized
			Single Lane	Multi-Lane				
Stop	R1-1	2B.05	30 x 30*	36 x 36	36 x 36	—	30 x 30*	48 x 48
Yield	R1-2	2B.08	36x36x36*	48x48x48	48x48x48	60x60x60	30x30x30*	—
To Oncoming Traffic (plaque)	R1-2aP	2B.10	24 x 18	24 x 18	36 x 30	48 x 36	24 x 18	—
All Way (plaque)	R1-3P	2B.05	18 x 6	18 x 6	—	—	—	30 x 12
Yield Here to Peds	R1-5	2B.11	—	36 x 36	—	—	—	36 x 36
Yield Here to Pedestrians	R1-5a	2B.11	—	36 x 48	—	—	—	36 x 48
Stop Here for Peds	R1-5b	2B.11	—	36 x 36	—	—	—	36 x 36
Stop Here for Pedestrians	R1-5c	2B.11	—	36 x 48	—	—	—	36 x 48
In-Street Ped Crossing	R1-6,6a	2B.12	12 x 36	12 x 36	—	—	—	—
Overhead Ped Crossing	R1-9,9a	2B.12	90 x 24	90 x 24	—	—	—	—
Except Right Turn (plaque)	R1-10P	2B.05	24 x 18	24 x 18	—	—	—	—
Speed Limit	R2-1	2B.13	24 x 30*	30 x 36	36 x 48	48 x 60	18 x 24*	30 x 36
Truck Speed Limit (plaque)	R2-2P	2B.14	24 x 24	24 x 24	36 x 36	48 x 48	—	36 x 36
Night Speed Limit (plaque)	R2-3P	2B.15	24 x 24	24 x 24	36 x 36	48 x 48	—	36 x 36
Minimum Speed Limit (plaque)	R2-4P	2B.16	24 x 30	24 x 30	36 x 48	48 x 60	—	36 x 48
Combined Speed Limit	R2-4a	2B.16	24 x 48	24 x 48	36 x 72	48 x 96	—	36 x 72
Unless Otherwise Posted (plaque)	R2-5P	2B.13	24 x 18	24 x 18	—	—	—	—
Citywide (plaque)	R2-5aP	2B.13	24 x 6	24 x 6	—	—	—	—
Neighborhood (plaque)	R2-5bP	2B.13	24 x 6	24 x 6	—	—	—	—

Standard Highway Signs

The "Standard Highway Signs and Markings" book, commonly referred to as the SHS, is a publication that provides standardized designs and specifications for traffic signs and pavement markings used on public roadways in the United States. It is published by the Federal Highway Administration (FHWA) and serves as a companion to the Manual on Uniform Traffic Control Devices (MUTCD).

[Standard Highway Signs—PDF and EPS files for New and Revised Signs - FHWA MUTCD \(dot.gov\)](#)



Standard Highway Signs – sign details and radius




* See page X-XX for symbol design


A	B	C	D	E	F	G	H	J
18	0.375	0.625	4.688	8.625	1.5	7.875	6.375	1.5
24	0.375	0.625	6.25	11.5	2	10.5	8.5	1.5
30	0.5	0.75	7.813	14.375	2.5	13.125	10.625	1.875

COLORS: LEGEND, BORDER – BLACK
 CIRCLE, DIAGONAL – RED (RETROREFLECTIVE)
 BACKGROUND – WHITE (RETROREFLECTIVE)

Blade Width - Minimum Radius



Standard Highway Signs – sign details and radius



Sign Spacing:

Sign Letter spacing is determined by the Standard Highway Signs and Markings book. It will have every known sign available to get the proper measurements of sign blank, radius, letter spacing, and letter height.

Signs & Markings II

Sign Fabrication



Advancing the Future of Public Safety



Advancing the Future of Public Safety

Tools of the Trade

Here are some essential tools for weeding out traffic signs:

- 1. Weeding Tool:** A weeding tool, also known as a weeder or a weeding hook, is a small handheld tool with a sharp point or hook-like tip. It is used to carefully lift and remove the excess vinyl material from the sign. The tool should have a comfortable grip and a precise tip to navigate around fine details.
- 2. Tweezers:** Tweezers can be handy for picking up and removing small vinyl pieces or debris left behind after weeding. They provide more control when handling delicate or intricate parts of the sign.
- 3. Magnifying Glass:** For intricate designs or small text, a magnifying glass or a magnifying lamp can be helpful. It allows for better visibility and precision during the weeding process.
- 4. Cutting Mat:** A self-healing cutting mat is commonly used as a protective surface while weeding out the sign. It helps prevent damage to the work area and ensures clean cuts without leaving behind unwanted marks.
- 5. Transfer Tape:** Masking tape is used to secure the sign design to the cutting mat, making it easier to work with and preventing any movement or misalignment during the weeding process.
- 6. Vinyl Release Agent:** In some cases, especially when working with adhesive vinyl that is difficult to weed, a vinyl release agent can be used. This agent is applied to the vinyl before weeding, making it easier to separate the excess material from the design.



Application Table

A squeeze rolling table, also known as an application table, is a specialized piece of equipment used in traffic sign fabrication for the application of vinyl films onto sign substrates. It is designed to ensure efficient and accurate placement of the vinyl film, creating a smooth and bubble-free surface. The table typically consists of a flat surface with a roller mechanism and may include additional features for improved functionality.

1. Here are some key aspects and benefits of using a squeeze rolling table or application table in traffic sign fabrication:
2. Flat and Stable Surface
3. Roller Mechanism
4. Uniform Pressure Distribution
5. Time and Labor Efficiency
6. Bubble-Free Results
7. Versatility
8. Consistency and Accuracy
9. Ergonomic Design



Advancing the Future of Public Safety

3 Primary Types of sign sheeting


Engineer Grade Sheeting (Type I):

- Reflectivity: Engineer grade sheeting provides moderate reflectivity.
- Standards: In the United States, engineer grade sheeting is classified under ASTM D4956 Type I. Its minimum retroreflectivity values are outlined in the Manual on Uniform Traffic Control Devices (MUTCD) published by the FHWA.



High-Intensity Prismatic Sheeting (Type III):


- Reflectivity: High-intensity prismatic sheeting offers increased reflectivity compared to engineer grade sheeting.
- Standards: In the United States, high-intensity prismatic sheeting is classified under ASTM D4956 Type III. Its minimum retroreflectivity values are outlined in the MUTCD.



Diamond Grade Sheeting (Type XI):

- Reflectivity: Diamond grade sheeting provides the highest level of reflectivity among the three types.
- Standards: In the United States, diamond grade sheeting is classified under ASTM D4956 Type XI. Its minimum retroreflectivity values are outlined in the MUTCD.





Engineer Grade Sheeting (Type I)

- **Type 1 traffic sign sheeting** refers to a specific classification of retroreflective sheeting used for traffic signs. It is often referred to as **Engineer Grade Sheeting**. Here are some key characteristics and features of **Type 1 traffic sign sheeting**:
 - **Reflectivity**: Type 1 sheeting offers moderate reflectivity, providing a basic level of visibility for traffic signs. It reflects light back to the source, enhancing sign visibility during nighttime or low-light conditions.
 - **Construction**: Type 1 sheeting is typically composed of a monolayer of acrylic or other polymers with embedded glass beads or microprisms. These reflective elements help to redirect light back to its source, improving sign visibility.
 - **Durability**: While Type 1 sheeting offers basic reflectivity, it is generally considered to have a lower durability compared to higher-grade sheeting types. It may be less resistant to fading, cracking, and damage from environmental factors such as UV radiation and weather conditions.
 - **Application**: Type 1 sheeting is commonly used for non-critical signs, such as parking lot signs, signs on private property, or in areas with low traffic volume and slower speeds. It may also be suitable for temporary signs or short-term applications.
 - **Standards**: In the United States, Type 1 sheeting meets the reflectivity standards outlined in ASTM D4956 Type I and the requirements specified by the Manual on Uniform Traffic Control Devices (MUTCD). The MUTCD provides guidelines for the design and placement of traffic signs to ensure uniformity and consistency across roadways.

High-Intensity Prismatic Sheeting (Type III)

HIP sheeting is constructed using multiple layers of prismatic lenses that enhance the reflection of light. These lenses are designed to reflect light back to its source, making the sign more visible to drivers, particularly during low-light conditions or at night.

Some key features and characteristics of High-Intensity Prismatic (HIP) Sheeting include:

- 1. Increased Reflectivity:** HIP sheeting provides a higher level of reflectivity compared to Engineer Grade Sheeting. This increased reflectivity helps improve sign visibility, especially from longer distances.
- 2. Durability:** HIP sheeting is designed to withstand the outdoor elements and has excellent resistance to fading, cracking, and weathering. It is often made with durable materials such as acrylic or polycarbonate to ensure long-term performance.
- 3. Color Options:** High-Intensity Prismatic sheeting is available in a variety of colors, including white, yellow, red, green, and blue. This allows for the creation of signs with different colors and designs to convey specific messages and comply with traffic regulations.
- 4. Compliance Standards:** High-Intensity Prismatic (HIP) Sheeting meets the reflectivity standards specified by transportation authorities and organizations. In the United States, these standards are outlined in the Manual on Uniform Traffic Control Devices (MUTCD) published by the Federal Highway Administration (FHWA).



Diamond Grade Sheeting (Type XI)

Diamond grade sheeting is a type of reflective material commonly used in traffic signs, road markings, and other applications that require high visibility, particularly during nighttime and low-light conditions. It is named for its diamond-shaped microprismatic optical elements that enhance reflectivity. Here are the key aspects of diamond grade sheeting:

- 1. Reflectivity:** Diamond grade sheeting offers excellent reflectivity due to its microprismatic design. It reflects light back to the source, enhancing visibility and improving safety on the road.
- 2. Visibility and Conspicuity:** The reflective properties of diamond grade sheeting make signs and markings highly visible, even in adverse weather conditions such as rain, fog, or darkness. This helps drivers quickly identify signs and navigate roads more safely.
- 3. Performance Grades:** Diamond grade sheeting is available in different performance grades, such as DG3 (highest performance) and DG2. These grades indicate the level of reflectivity and durability. DG3 sheeting provides the highest level of performance and is typically used for critical signs like stop signs and warning signs.
- 4. Durability:** Diamond grade sheeting is designed to be durable and resistant to environmental factors, such as UV radiation, humidity, and temperature fluctuations. It has a longer lifespan compared to lower-grade reflective materials.
- 5. Compliance with Standards:** Diamond grade sheeting typically meets or exceeds various national and international standards, such as the ASTM D4956 Type XI specification in the United States and the EN 12899-1 standard in Europe. Compliance with these standards ensures consistent performance and quality.
- 6. Application Versatility:** Diamond grade sheeting is suitable for a wide range of applications, including traffic signs, pavement markings, vehicle markings, barricades, and work zone signage. It can be used on various substrates, such as metal, plastic, and concrete.



Sign Fabrication Methods

Silk screening

- High volume of the same type of sign
- Needs a dedicated area & chemicals
- Needs time to dry

Cut and plot

- Medium to low quantities
- Flexible on design
- Relatively inexpensive

Digital printing

- Medium/high quantities
- Flexible on design
- More expensive than cut & plot
- Most efficient

Silk Screening

- **Steps To Silk Screening**


- Design / obtain design of sign
- Prepare the screen
- Apply Emulsion
- Create a film Positive
- Prepare the exposure setup
- Wash out the design
- Dry the screen
- Setup print station
- Apply ink
- Print the sign
- Cure the Ink
- Inspect and finish



Cut and Plot

• Steps To Cut and Plot

- Design / obtain design of sign
- Load the proper Material in your plotter.
- Send the file from the computer program (SignCAD, TrafficCAD, CŌCUT, Flexi, ETC) to the plotter and let it cut the proper lines.
- Remove material from plotter and transfer to a flat surface
- Weed out the material that is not needed.
- Use Transfer Tape to hold the little pieces in place
- Line up the face of the sign on the substrate making sure it was centered.
- Apply with Rolling apparatus
- Use **utility knife** to trim off the excess around the edge of the substrate.





Cut and Plot

One key to successfully plotting a sign is to be sure you have a sharp cutting edge.

- Dull Edge – may drag the material and not cut the rest completely which will leave unfinished cuts.
- If you are having issues removing the material from the backing you should try to lower the pressure a bit.
- If you are plotting a sign with a lot of tiny components you would want to turn down the speed of the cut. This will allow it to cut more accurately.



Cut and Plot



Removing a sign from the plotter:

To ensure the sign remains intact there is a few options to consider.

- **Cutting Settings:** Before cutting the sign on the plotter, make sure to adjust the cutting settings appropriately. If the cutting pressure is too high, it may cut too deeply into the vinyl and increase the risk of tearing or damaging the sign. Similarly, if the cutting speed is too fast, it might cause the vinyl to lift or stretch, leading to potential issues during removal. Adjusting these settings based on the type and thickness of the vinyl material can help ensure a cleaner cut and easier removal process.
- **Test Cuts:** It's always a good idea to perform test cuts on a small portion of the vinyl material before cutting the entire sign. This allows you to check if the cutting settings are appropriate and make any necessary adjustments before committing to the full sign. By doing test cuts, you can identify any potential issues or errors early on and avoid damaging the entire sign.
- **Slow and Controlled Removal:** When removing the sign from the plotter, do it slowly and with care. Gently lift one corner or edge of the sign and slowly peel it away from the vinyl backing. By taking your time and being cautious during the removal process, you can minimize the risk of tearing or leaving behind any unwanted portions.



Cut and Plot

Another issue you may come across is material running on the plotter.

- If your material begins to run, which means moving to the side off the rollers which could jam the plotter or have a deformed sign. This is usually because the material becomes loose on the roll. Cut off the wasted material and remove the roll from the machine. Which both hands, tighten the roll up and load it back on the machine making sure that the rollers are on the material and locked in position.



Cut and Plot



Maintaining the Plotter and Tools

- Be sure to keep the pinch rollers clean and free of debris to ensure proper tracking. Pinch rollers are important for feeding the material through the plotter.
- A plotter is not a difficult machine to maintain. It is always best to keep some spare blades on hand if you need to replace a dull blade. Wiping it down regularly will keep the machine free of dust and debris and be sure to clean out your material catching system.
- The tools used generally being a Utility Knife, Exacto Knife, Tweezers, and squeegees. It is best to keep extra blades on hand to replace dull Knife blades.
- Proper maintenance will allow continued quality production.



Weeding / reverse Weeding

Weeding

- refers to the process of removing excess vinyl material from a cut or printed design, leaving behind only the desired graphic or lettering. It is an essential step in sign-making, particularly when working with adhesive vinyl or heat transfer vinyl.
- This is done by following the lines of the design and removing the negative space or areas that are not part of the intended graphic or text.
- Weeding allows for the creation of clean and precise designs, where the vinyl graphics or text stand out against the background or substrate.



Weeding / reverse Weeding

Reverse Weeding

- Reverse weeding, on the other hand, is a variation of the traditional weeding process. It is used when working with certain types of vinyl or designs where the smaller or more intricate pieces are easier to handle and weed if the process is reversed.
- In reverse weeding, instead of removing the excess vinyl material, the desired design elements are weeded and kept intact, while the surrounding or background vinyl is removed. This technique is often used for intricate designs or when dealing with designs that have a lot of small details or lettering.
- Reverse weeding can be particularly useful when working with vinyl that has a strong adhesive or when the design requires delicate handling to avoid damaging the smaller elements. It allows for greater control and ease during the weeding process, ensuring that the desired design remains intact.



Digital Printing

Steps For Digital Printing

- Design / obtain design of sign
- Load the proper Material in your Printer
- Send the file from computer using Flexi or other application
- While it is printing you can cut your laminate to fit the sign.
- Remove from Printer and lay on flat surface.
- Use a rolling Apparatus to apply the laminate to the printed sign.
- Lay the material onto a substrate like a metal blank and use the roller to apply.
- Use **Utility Knife** to trim off the excess material from around the substrate.



Digital Printing

Benefits of Digital Printing

- Less material waste
- Less need for transfer tape
- The ability to print multiple colors on a single sign.
- Saves money over time compared to other fabrication processes.



Digital Printing

Common Issues in Digital Printing for Traffic Signs and Solutions:

1. Color inconsistencies: Ensure that the color profile and settings on the printer match the design file. Regularly calibrate the printer to maintain color accuracy.
2. Banding or streaking: Clean the printheads Daily and ensure they are properly aligned. If the issue persists, consider replacing or servicing the printheads.
3. Print quality issues: Check the print heads, ink levels, and media settings. Perform test prints and adjust print settings as needed. If necessary, replace or repair faulty components.
4. Adhesion problems: Ensure the sign substrate is clean and properly prepared before printing. Consider using adhesion promoters or specialized inks for better ink adhesion to the substrate.
5. Media jams or misfeeds: Regularly clean the media feed rollers and ensure they are in good condition. Adjust the media settings and avoid overloading the printer with heavy or stiff materials.

Squeegee Roller applicator

Squeegee roller applicator

A squeegee roller applicator is a tool used for applying pressure and smoothing surfaces, particularly in the context of vinyl application, such as sign making or vehicle wraps. It typically consists of a handle and a roller mechanism.



Squeegee Roller applicator

Squeegee roller applicator issues

Always be sure to center your blank and material under the center of the roller. Doing this will reduce the likeliness of the material running when you apply it to the blank. This is caused by uneven pressure applied to the substrate.



Laminate application types

Typically there are three ways laminate can be applied.



- Machine roller



- Vacuum Press



- Manual roller

Signs & Markings II

Sign Fabrication - Review



Advancing the Future of Public Safety

Knowledge Check: Multiple Choice

When making a 6" Street name sign on a large squeeze roller applicator, the sign material keeps wrinkling or tracking off center. What can be done to remedy the issue?

- a. Adjust the air regulator pressure
- b. Adjust speed controls on roller
- c. Center the blank in the middle of the roller
- d. Try using different material

Knowledge Check: Multiple Choice

To ensure good tracking and alignment of the vinyl material, which part of the plotter should be kept clean from adhesive and debris?

- a. Grit rollers
- b. Material sensor
- c. Pinch rollers
- d. plunger

Application of Laminate vinyl to signs may be done in all the following ways EXCEPT by

- a. Machine roller
- b. Manual roller
- c. Torch
- d. Vacuum press

What is the purpose of the pinch rollers on a plotter?

- a. Apply the vinyl
- b. Feed the vinyl being cut
- c. Roll out the sheeting
- d. Squeeze out air bubbles

Printer and plotter preventative maintenance is important in order to

- a. Decrease quality output
- b. Decrease quantity output
- c. Increase quality output
- d. Increase quantity output

Knowledge Check: Multiple Choice

What can be used manually or automatically that can help ensure that the entire sign will be intact when removing it from the plotter?

- a. Cutter calibration
- b. Material advance
- a. Material sensor adjustment
- b. Test cut

What variable determines the MINIMUM dimensions of a sign according to the MUTCD?

- a. Current inventory
- b. Mounting surface
- c. Roadway Speed
- d. Shape

A custom sign must be cut with small intricate designs. What adjustment should be made to make successful cuts?

- a. Decrease cut pressure
- b. Decrease cut speed
- a. Increase cut pressure
- b. Increase cut speed

Knowledge Check: Multiple Choice

Which of the following warning signs are permitted to use other colors in addition to yellow?

- a. No outlet
- b. Pedestrian Crossing
- c. Raised Humps
- d. Reduced Speed Limit Ahead

Knowledge Check: Multiple Choice

The corner radius of a 30" square traffic sign is

- a. 1.5 inches
- b. 1.875 inches
- c. 2.25 inches
- d. 5 inches

Knowledge Check: Multiple Choice

If used frequently, how often should a printhead be maintained?

- a. Daily
- b. Weekly
- c. Monthly
- d. Annually

An IMSA signs & markings Tech II is plotting a sign. What does the technician use to determine the size for the roll of material?

- a. The plotter orientation
- b. The sign height
- c. The sign orientation
- d. The sign width

What is an essential part of maintaining a plotter?

- a. Keeping it online
- b. Keeping it plugged in
- c. Keeping the blade sharp
- d. Keeping vinyl in the rack

Knowledge Check: Multiple Choice

In sign fabrication, what tool may be used to trim excess material from the substrate?

- a. Pocket Knife
- b. Razor blade
- c. Scissors
- d. Utility Knife

Knowledge Check: Multiple Choice

When transferring vinyl to the sign blank, the paper backing is coming off with the vinyl. What is the likely cause of this problem?

- a. Incorrect vinyl material
- b. Plotter pressure was too high
- c. Plotter speed was too slow
- d. Transfer tape adhesion problem

When weeding a sign and the material is hard to remove, what could be done to remedy the problem?

- a. Decrease the plotter pressure
- b. Decrease the plotter speed
- c. Increase the plotter pressure
- d. Use a different weeding tool

What type of sign material is needed to affix lettering onto a substrate?

- a. Double-sided tape
- b. Friction tape
- c. Masking tape
- d. Transfer Tape

What type of sign material is needed for the highest retroreflectivity?

- a. Diamond grade
- b. EC film
- c. Engineer grade
- d. Laminate

In sign design, how is letter spacing determined for a traffic sign?

- a. by the font type used
- b. by the MUTCD
- c. By the size of the sign
- d. By the Standard Highway Signs and Markings Book

Signs & Markings II

Line Locates



Advancing the Future of Public Safety



[Before You Dig](#) [Start Here](#) [811 In Your State](#) [811 Tips](#) [Storm Recovery](#)

**SAFETY IS IN YOUR HANDS.
EVERY DIG. EVERY TIME.**



Line Locates - [Call 811 - Know what's below. Call before you dig.](#)

Before any Installation – Line Locates

Underground utilities should be located before installing signs or conducting any excavation work to prevent accidental damage to the utilities. The primary reasons for locating underground utilities are:

- **Safety:** Hitting underground utilities can lead to severe accidents, injuries, or even fatalities. Locating them beforehand ensures the safety of workers and the public.
- **Cost and Time Efficiency:** Damaging underground utilities can result in costly repairs, project delays, and disruptions to essential services. Locating utilities in advance helps avoid these issues and ensures efficient project execution.




Before any Installation – Line Locates

It generally takes 48 – 72 hours for the utility marking company to respond and Typically, line locates are valid for a certain period, usually ranging from a few weeks to a couple of months. It is essential to check with the local utility providers or the responsible authorities to determine the exact validity period in your area.

If utilities have been marked but for some circumstance the work is unable to be completed before the markings expire, just renew the ticket with the locators and give them the same 48 – 72 hour period.

When utility lines are located, they are marked with specific colors to indicate the type of utility. While color codes may vary slightly between regions, the general color codes for utility markings are:





Advancing the Future of Public Safety

Before any Installation – Line Locate Contact Info

For line locates in the states of Texas, Oklahoma, Arkansas, and Louisiana, you would typically contact the appropriate regional or state-level agency responsible for utility locating. Here are the relevant agencies for each state:

- **Texas:** In Texas, you would contact the Texas811 service. It is a one-call notification center that helps coordinate utility line locates across the state. You can reach them by dialing 811 or visiting their website at <https://www.texas811.org/>.
- **Oklahoma:** In Oklahoma, you would contact the Oklahoma One-Call System. They are responsible for coordinating utility line locates in the state. You can reach them by dialing 811 or visiting their website at <https://www.okie811.org/>.
- **Arkansas:** In Arkansas, you would contact the Arkansas One Call. They provide a central point of contact for utility line locates in the state. You can reach them by dialing 811 or visiting their website at <https://www.arkonecall.com/>.
- **Louisiana:** In Louisiana, you would contact the Louisiana One Call System. They are responsible for coordinating utility line locates in the state. You can reach them by dialing 811 or visiting their website at <https://www.laonecall.com/>.

Signs & Markings II

Line Locate - Review



Advancing the Future of Public Safety

Knowledge Check: Multiple Choice

If an IMSA signs & markings technician II sees a utility is not marked after waiting the required time, what should the tech do?

- a. Call the local utility company
- b. Contact utility locate service
- c. mark the utilities for them
- d. start work

What should an IMSA signs & markings technician II do if their utility service account ticket is expired?

- a. Continue working
- b. Don't tell anyone
- c. Remark themselves
- d. Renew the ticket

Knowledge Check: Multiple Choice

A utility locate request call has been made. According to the MUTCD, how long should you wait to follow up or perform work?

- a. 4 to 8 hours
- b. 8 to 16 hours
- c. up to 1 day
- d. 2 to 3 days

A work order is created for a new sign installation. What should a Tech do first?

- a. Assemble the sign
- b. Get locates
- c. Install the post
- d. Make the sign

Signs & Markings II

Sign Installation – Placement considerations



Advancing the Future of Public Safety



Considerations to sign installation placement



Determining placement of signs - Topography

Topography plays a crucial role in sign installation for several reasons.

Visibility and Line of Sight:

Topography can affect the visibility of traffic signs. Hills, slopes, or curves in the terrain may obstruct the line of sight for drivers, making it challenging for them to see and read signs. In such cases, it becomes crucial to position signs at locations where they are visible to approaching motorists, taking into account sight distance requirements and potential visual obstructions caused by the topography.



Visibility and Readability

When installing traffic signs near hills and curves, there are specific rules and guidelines to ensure road safety and provide appropriate warnings to drivers. The rules may vary depending on local regulations and engineering standards, but here are some general considerations:

- 1. Regulatory Signs:** Regulatory signs, such as speed limit signs, stop signs, or no passing signs should be placed before the curve or hill, providing drivers with sufficient notice and time to adjust their speed or take necessary actions. The distance between regulatory signs and the hazard should be determined based on engineering judgment, considering factors like the speed of traffic and visibility.



Visibility and Readability

When installing traffic signs near hills and curves, there are specific rules and guidelines to ensure road safety and provide appropriate warnings to drivers. The rules may vary depending on local regulations and engineering standards, but here are some general considerations:

- 1. Warning Signs:** Warning signs are crucial in alerting drivers to the presence of a hill or curve ahead. These signs typically have a yellow background with black symbols or text. Consider the following guidelines when installing warning signs:
 - a. Hill Warning Signs: Install "Hill" warning signs in advance of an uphill section to alert drivers of the upcoming change in road grade. The signs may include additional information, such as the grade percentage or distance of the hill.




Structural Considerations

1. Curve Warning Signs:

Install "Curve" warning signs before a curved section to alert drivers of the upcoming change in direction. The signs may indicate the recommended speed for navigating the curve or display an arrow indicating the direction of the curve.

2. Chevron Signs:

Chevron signs are often used in combination with warning signs to provide additional emphasis for curves. These signs consist of a series of yellow, diagonal arrows pointing in the direction of the curve. They help visually guide drivers through the curve and enhance awareness of the upcoming road alignment change.



Signs & Markings II

Sign Installation – Placement consideration Review



Advancing the Future of Public Safety

Knowledge Check: Multiple Choice

A No Passing sign is being installed on a hilly roadway. Where should the sign be installed?

- a. At the base of the hill
- b. On the crest of the hill
- c. In the middle of the hill
- d. On the downward side of the hill

Knowledge Check: Multiple Choice

Where engineering judgement determines the need to draw attention to a sign during nighttime conditions, what can be added to a sign post?

- a. Flashing beacon
- b. Strip of retroreflective material
- c. Traffic Paint
- d. Whirly gig

Knowledge Check: Multiple Choice

A speed limit sign beacon shall be used only to _____ a speed limit sign.

- a. backup
- b. duplicate
- c. replace
- d. supplement

Signs & Markings II

Traffic Counts and Traffic Warrants



Advancing the Future of Public Safety

Traffic Counts and Warrants



What are Warrants for Traffic Control Devices?

A warrant is basically a criteria used by several road departments to find out whether a traffic control device is needed at an intersection or on the street, highway or road. The criteria for a warrant for signs are:

- A sign or signal that needs to attract the attention, such as a 'Signs of One Way'
- Signs that lay down the law such as 'Fines Double in Construction Zones'
- Fulfillment of something considered necessary, such as accident reduction
- Gives a driver a clear direction as to where they need to go, such as a directional sign
- Signs that let you know something is about to change, such as 'Road Closed in 1 Mile'



Traffic Counts

Traffic counts, or traffic surveys, are conducted at various times and intervals depending on the specific objectives and requirements of the study. Here are some common scenarios and reasons when traffic counts are typically performed:

- Transportation Planning
- New Development Impact Assessment
- Intersection Analysis and Design
- Roadway Capacity Analysis
- Safety Studies
- Traffic Impact Studies
- Special Events

The timing and duration of traffic counts depend on the specific objectives and context of the study. Counts can be conducted for short durations, such as a few hours or days, to capture peak traffic periods or for longer periods to assess daily or seasonal variations. Typically, A total of eight hours of turning movement is generally mandated for this type of assessment..

EXAMPLES OF TRAFFIC VOLUME COUNT STUDIES

Intersection counts are used for timing traffic signals, designing channelization, planning turn prohibitions, computing capacity, analyzing high crash intersections, and evaluating congestion (Homburger et al. 1996). The manual count method is usually used to conduct an intersection count. A single observer can complete an intersection count only in very light traffic conditions.

The intersection count classification scheme must be understood by all observers before the count can begin. Each intersection has 12 possible movements (see Figure 3.6). The intersection movements are through, left turn, and right turn. The observer records the intersection movement for each vehicle that enters the intersection.

Traffic Counts

Pedestrian Counts

Pedestrian count data are used frequently in planning applications. Pedestrian counts are used to evaluate sidewalk and crosswalk needs, to justify pedestrian signals, and to time traffic signals. Pedestrian counts may be taken at intersection crosswalks, midblock crossings, or along sidewalks.

Vehicle Classification Counts

Vehicle classification counts are used in establishing structural and geometric design criteria, computing expected highway user revenue, and computing capacity. If a high percentage of heavy trucks exists or if the vehicle mix at the crash site is suspected as contributing to the crash problem, then classification counts should be conducted.

Typically cars, station wagons, pickup and panel trucks, and motorcycles are classified as passenger cars. Other trucks and buses are classified as trucks. School buses and farm equipment may be recorded separately. The observer records the classification of the vehicles and the vehicles' direction of travel at the intersection.

Average Daily Traffic and Annual Average Daily Traffic Counts

Average daily traffic (ADT) counts represent a 24-hour count at any specified location. These counts are obtained by placing an automatic counter at the analysis location for a 24-hour period. Accuracy of the ADT data depends on the count being performed during typical roadway, weather, and traffic demand conditions. Local levels of government will typically conduct this type of count.

Annual average daily traffic (AADT) counts represent the average 24-hour traffic volume at a given location averaged over a full 365-day year. AADT volume counts have the following uses:

- measuring or evaluating the present demand for service by the roadway or facility
- developing the major or arterial roadway system
- locating areas where new facilities or improvements to existing facilities are needed
- programming capital improvements

Traffic Counts

Traffic count studies can range in duration based on various factors including the purpose of the study, the type of road, and the specific traffic characteristics that are being investigated. However, for general purposes, a typical traffic count is conducted over a 24-hour period. This gives a complete picture of traffic flow for an average day, including peak and off-peak hours.

For more detailed studies or where the data is being used to inform substantial infrastructure investments, counts may be carried out over a longer period such as a week, a month, or even a year to understand seasonal variations, impact of holidays, and other long-term trends.

However, the duration of the study should be sufficient to provide representative data that isn't overly influenced by temporary conditions or unusual circumstances. For example, conducting a traffic count on a holiday or during a major event that disrupts normal traffic patterns could provide misleading data if used as an indication of typical conditions.

So, while the minimum duration might technically be less than 24 hours for specific studies, most professionals would recommend at least a 24-hour count for a broad understanding of traffic patterns. Always consult with local authorities or traffic engineering professionals for standards and practices in your specific location.

Turn Movement Counts

Turning Movement Count (TMC) is a key part of transportation engineering studies. It is a detailed count of vehicles, pedestrians, or cyclists as they move through an intersection, documenting the number and direction of these movements. It is used to understand how traffic operates at specific intersections and aids in decision-making for traffic signal timings, road layout, and safety improvements.

Typically, TMC records the following turning movements at intersections:

- Left turn
- Right turn
- Straight-through

This data can be recorded manually by individuals or through automated methods like cameras or sensors. TMC is vital for evaluating the effectiveness of traffic control measures, determining the need for modifications to the existing infrastructure, planning for future development, and conducting accident analyses.

Traffic Warrants

Traffic warrants refer to a set of established criteria or guidelines used by transportation professionals, traffic engineers, and local authorities to determine if specific traffic control measures or infrastructure improvements are necessary at a particular location. These warrants help ensure that the implementation of traffic control devices, such as traffic signals, stop signs, or other traffic control measures, is justified based on specific traffic and safety conditions.

Different types of traffic control devices, such as traffic signals, stop signs, yield signs, or pedestrian crossings, may have their own set of warrants. The specific warrants can vary depending on local regulations, engineering practices, and the context of the location being evaluated. However, some common factors considered in traffic warrants include:

- Traffic Volume
- Intersection or Roadway Configuration
- Crash History and Safety
- Pedestrian and Bicycle Activity
- Delay and Level of Service
- Special Conditions

Traffic Warrants – Traffic Volume

Table 4C-1. Warrant 1, Eight-Hour Vehicular Volume

Condition A—Minimum Vehicular Volume

Number of lanes for moving traffic on each approach		Vehicles per hour on major street (total of both approaches)				Vehicles per hour on higher-volume minor-street approach (one direction only)			
Major Street	Minor Street	100% ^a	80% ^b	70% ^c	56% ^d	100% ^a	80% ^b	70% ^c	56% ^d
1	1	500	400	350	280	150	120	105	84
2 or more	1	600	480	420	336	150	120	105	84
2 or more	2 or more	600	480	420	336	200	160	140	112
1	2 or more	500	400	350	280	200	160	140	112

Condition B—Interruption of Continuous Traffic

Number of lanes for moving traffic on each approach		Vehicles per hour on major street (total of both approaches)				Vehicles per hour on higher-volume minor-street approach (one direction only)			
Major Street	Minor Street	100% ^a	80% ^b	70% ^c	56% ^d	100% ^a	80% ^b	70% ^c	56% ^d
1	1	750	600	525	420	75	60	53	42
2 or more	1	900	720	630	504	75	60	53	42
2 or more	2 or more	900	720	630	504	100	80	70	56
1	2 or more	750	600	525	420	100	80	70	56

^a Basic minimum hourly volume

^b Used for combination of Conditions A and B after adequate trial of other remedial measures

^c May be used when the major-street speed exceeds 40 mph or in an isolated community with a population of less than 10,000

^d May be used for combination of Conditions A and B after adequate trial of other remedial measures when the major-street speed exceeds 40 mph or in an isolated community with a population of less than 10,000

Signs & Markings II

Traffic Counts and Traffic Warrant Review



Advancing the Future of Public Safety

What does a Tech typically do upon completing a Turning Movement Count (TMC)?

- a. Clear the data
- b. Record or upload the data
- c. Store the box
- d. Store the tubes

Typically how many hours of data is needed for a sufficient turning movement count (TMC)?

- a. One hour
- b. Two hours
- c. Four hours
- d. Eight hours

When a Tech receives a work order from engineering to set up a traffic count. What should the technician do?

- a. Call for a utility locate
- b. Change the signs and markings prior to the count
- c. Conduct the count in one day
- d. Do a site survey/site sketch

When should a traffic count be done?

- a. After a project is completed
- b. During closeout inspection
- c. During the construction phase
- D. During the planning phase of the project.

What is the definition of a turning movement count (TMC)?

- A. TO count pedestrians, cycles or vehicles which are moving towards an intersection
- B. To count the cycles of a traffic signal in an intersection
- C. To count the pedestrian crossing movements
- D. To count the people pushing the crosswalk button

Knowledge Check: Multiple Choice

During a traffic count, bikes and vehicles are counted. What else should be considered?

- a. Animals
- b. Jaywalkers
- a. Panhandlers
- b. Pedestrians

Knowledge Check: Multiple Choice

What is the MINIMUM length of time a traffic count should be conducted?

- a. 2 hours
- b. 6 hours
- c. 24 hours
- d. 48 hours


Signs & Markings II

Speed Display Board / Trailer



Advancing the Future of Public Safety

Speed Display Board / Trailer



Speed Display Board / Trailer

A speed display board, also known as a speed sign or radar speed sign, is an electronic device used to display the speed of vehicles to drivers on the road. It is designed to provide real-time feedback to motorists about their current speed, promoting awareness and encouraging them to adhere to speed limits. The primary purpose of a speed display board is to enhance road safety by reducing speeding and promoting responsible driving behavior.



Speed Display Board / Trailer

The key features and components of a typical speed display board include:

- **Display Panel:** The display panel is the main component of the speed display board. It consists of a digital or LED display that shows the speed of approaching vehicles. The display is usually large and easily visible from a distance, ensuring that drivers can quickly and clearly read their speed.
- **Radar or Sensor:** Speed display boards utilize radar technology or other sensors to detect the speed of oncoming vehicles. The radar or sensor is integrated into the device and measures the speed of passing vehicles accurately.
- **Speed Thresholds:** Speed display boards can be programmed with different speed thresholds or limits. When a vehicle exceeds the predetermined threshold, the display panel is activated, and the driver's speed is shown. The threshold can be set to correspond to the posted speed limit or customized based on specific road conditions or requirements.
- **Power Supply:** Speed display boards require a power source to operate. They are typically powered by electricity through a connection to the local power grid or by using solar panels for more remote or environmentally friendly installations.
- **Mounting and Housing:** Speed display boards are mounted on poles or other structures at the side of the road. They are designed to be durable, weather-resistant, and able to withstand various environmental conditions. The housing provides protection for the electronic components, ensuring the device's longevity and functionality.
- **Data Collection and Connectivity (optional):** Some speed display boards may include additional features such as data collection capabilities and connectivity. These boards can collect data on vehicle speeds, traffic patterns, or other relevant information. They may be equipped with wireless or network connectivity for remote monitoring and analysis.

Speed Display Board / Trailer

Placing the trailer:

Speed display boards / trailers can be mounted below a speed limit sign or if it is a trailer can be placed on the right shoulder of the road. When determining the placement of a speed display board, several factors should be considered to maximize its effectiveness in promoting safe driving behavior. Here are some key considerations for placing a speed display board:

- High-Traffic Areas
- Proximity to Speed Limit Changes
- Visibility and Line of Sight
- Adequate Warning Distance
- Strategic Placement within Communities
- Speeding Hotspots and Problem Areas
- Temporary Construction Zones
- Data Collection and Analysis
- Local Regulations and Guidelines
- Flexibility and Mobility

Speed Display Board / Trailer

programming the trailer:

Programming a speed display board involves configuring its settings, thresholds, and behavior to ensure accurate speed measurement and appropriate display functionality. It is based off the actual speed of the road and given a threshold of around 5 to 10 mph before flashing a warning to the driver. While specific programming methods may vary depending on the manufacturer and model of the speed display board, here is a general overview of the programming process:


- Accessing the Programming Interface
- Setting Speed Thresholds
- Configuring Display Behavior
- Adjusting Display Duration
- Customizing Messages (Optional)
- Time and Date Configuration
- Additional Configuration (Optional)
- Saving and Applying Settings

Tuning A Radar Trailer

Radar speed trailers, sometimes referred to as "speed display boards," use radar technology to measure the speed of passing vehicles and display the speed on an LED sign. This is usually for the purpose of traffic calming, reminding drivers of the speed limit to encourage safer driving habits.

The tuning process involves setting up the radar system correctly and checking its accuracy. While the exact procedure may vary based on the specific model of radar speed trailer, a typical procedure might involve the following steps:

- Set up the radar speed trailer in a safe and appropriate location, taking care to ensure it is well stabilized and correctly angled towards the road. The angle is usually straight to the oncoming traffic.
- Use the radar speed trailer's user interface (which could be a physical interface on the device or a software interface on a computer or other device) to adjust the radar settings, including the minimum and maximum speed display.




Tuning A Radar Trailer

Validate the radar speed trailer's accuracy. This is often done using a tuning fork.

A tuning fork is a tool that, when struck, vibrates at a specific frequency. For radar guns used by law enforcement (and similar radar systems), a tuning fork can be used to check the accuracy of the radar. The radar measures the Doppler shift of the return signal to determine speed, and a tuning fork's vibration frequency can simulate a particular speed.

In the context of a radar speed trailer, you would use a tuning fork that simulates a known speed, and you'd expect the radar speed trailer to display that speed when the vibrating tuning fork is placed in front of the radar.



Tuning A Radar Trailer

Here's a basic procedure for how this could work:

1. Strike the tuning fork against a soft surface to make it vibrate. It should be noted that the tuning fork should not be struck hard enough to damage it, but just enough to create the vibration.
2. Hold the vibrating tuning fork in front of the radar antenna. The radar should read the speed that corresponds to the tuning fork's frequency.
3. Compare the radar speed reading with the expected speed of the tuning fork. If there's a discrepancy, you might need to adjust the radar's calibration.
4. Repeat the process until the radar speed trailer is providing accurate readings.

The actual process for adjusting the radar's calibration will depend on the specific make and model of the radar speed trailer. It might involve adjusting settings on the radar unit itself, using a separate calibration tool, or using software provided by the manufacturer. Always refer to the manufacturer's instructions or consult with a qualified technician if you're unsure about any part of the process



Signs & Markings II

Speed Display Board / Trailer Review



Advancing the Future of Public Safety

A speed display board detects approaching vehicles with a

- a. camera
- b. clock
- c. infrared
- d. radar

After initial deployment, a speed display board can be modified if needed by

- a. Adjusting settings
- b. rebooting
- c. reinstalling
- d. rewiring

When using a speed display board, it should be placed

- a. On the center line
- b. At a dead end
- c. On the left shoulder of the road
- d. on the right shoulder of the road

Knowledge Check: Multiple Choice

When using a speed display board, it should be used where _____ is a known issue

- a. Parked vehicles
- b. Slow traffic
- c. speeding
- d. traffic

Knowledge Check: Multiple Choice

A speed display board will normally display the speed of _____ Vehicles.

- a. approaching
- b. departing
- c. parked
- d. the furthest

Knowledge Check: Multiple Choice

An IMSA signs & markings technician II should program the speed display board by setting a minimum and maximum based upon the _____ speed limit.

- a. 85th percentile
- b. average
- c. existing
- d. targeted

The programmed speed on a display board should be verified by

- a. Asking a passerby what their speed is as they drive by
- b. Reading the illumination display through a CCTV
- c. Riding and double checking against speed driven
- d. watching the displayed speed of the passing traffic

Signs & Markings II

Changeable Message Signs



Advancing the Future of Public Safety

Changeable Message Signs



A changeable message sign (CMS) is a traffic control device that is capable of displaying one or more **alternative** messages. Some changeable message signs have a blank mode when no message is displayed, while others display multiple messages with only one of the messages displayed at a time (such as OPEN/CLOSED signs at weigh stations).

Before Deployment Inspection

A Changeable Message Sign (CMS) or a Variable Message Sign (VMS) is typically a traffic control device that can display a wide range of messages to convey traffic and other important information to motorists.

Since the battery status checking method could vary based on the specific model of the CMS, it's important to consult the user manual provided by the manufacturer. However, here's a general guide to get you started:

- **Physical Inspection:** If it's a solar-powered sign with a backup battery, you might start by checking to see if the solar panel is clean and unobstructed. Then, inspect the battery to see if there are any signs of damage or corrosion.
- **On-Screen Display or Indicator Lights:** Some models might have a display screen or indicator lights that show the battery status. This could be something simple like a set of LEDs that light up to indicate the current battery level.
- **CMS Control Interface:** If the CMS has a control panel or a software interface, there might be a battery status indicator there. You might need to navigate through the menus or settings to find it.
- **Testing the Battery:** Some models might have a battery testing function. This could be a button that you press to test the battery, or it could be a function that you need to activate through the control panel or software interface.
- **Using a Multimeter:** If the battery is accessible and you have the necessary equipment, you could use a multimeter to test the battery. However, you should only do this if you're comfortable working with electronics and you're sure it won't void the warranty or cause other issues.





Advancing the Future of Public Safety

Changeable Message Signs

Changeable message signs have a large number of applications including, but not limited to, the following:

- Incident management and route diversion
- Warning of adverse weather conditions
- Special event applications associated with traffic control or conditions
- Control at crossing situations
- Lane, ramp, and roadway control
- Priced or other types of managed lanes
- Travel times
- Warning situations
- Traffic regulations
- Speed control
- Destination guidance

Changeable Message Signs - MUTCD

Message Standard:

Portable changeable message signs shall comply with the applicable design and application principles established in Chapter 2A. Portable changeable message signs shall display only traffic operational, regulatory, warning, and guidance information, and shall NOT be used for advertising messages.

1. Support:

[Section 6F.61](#) contains information regarding the use of arrow boards that use flashing or sequential displays for lane closures.

Guidance:

- 1. Except in the case of a limited-legend CMS (such as a blank-out or electronic-display changeable message regulatory sign) that is used in place of a static regulatory sign or an activated blank-out warning sign that supplements a static warning sign at a separate location, changeable message signs should be used as a supplement to and not as a substitute for conventional signs and markings.*
- 2. CMS should be limited to no more than three lines, with no more than 20 characters per line.*
- 3. The spacing between characters in a word should be between 25 to 40 percent of the letter height. The spacing between words in a message should be between 75 and 100 percent of the letter height. Spacing between the message lines should be between 50 and 75 percent of the letter height.*
- 4. Except as provided in [Paragraph 18](#), word messages on changeable message signs should be composed of all upper-case letters. The minimum letter height should be 18 inches for changeable message signs on roadways with speed limits of 45 mph or higher. The minimum letter height should be 12 inches for changeable message signs on roadways with speed limits of less than 45 mph.*

Changeable Message Signs - MUTCD

Message Standard:

The colors used for legends on portable changeable message signs shall comply with those shown in Table 2A-5.

Support:

Section 2L.04 contains information regarding the luminance, luminance contrast, and contrast orientation that is also applicable to portable changeable message signs. A changeable Message Sign like any other Traffic sign should command Attention and Respect.

Section 2L.03 Legibility and Visibility of Changeable Message Signs

Changeable message signs used on roadways with speed limits of 55 mph or higher should be visible from 1/2 mile under both day and night conditions. The message should be designed to be legible from a minimum distance of 600 feet for nighttime conditions and 800 feet for normal daylight conditions. When environmental conditions that reduce visibility and legibility are present, or when the legibility distances stated in the previous sentences in this paragraph cannot be practically achieved, messages composed of fewer units of information should be used and consideration should be given to limiting the message to a single phase (see [Section 2L.05](#) for information regarding the lengths of messages displayed on changeable message signs).

Changeable Message Signs – Acceptable Abbreviations

Table 1A-1. Acceptable Abbreviations

Word Message	Standard Abbreviation
Afternoon / Evening	PM
Alternate	ALT
AM Radio	AM
Avenue	AVE, AV
Bicycle	BIKE
Boulevard	BLVD*
Bridge	(See Table 1A-2)
CB Radio	CB
Center (as part of a place name)	CTR
Circle	CIR*
Civil Defense	CD
Compressed Natural Gas	CNG
Court	CT*
Crossing (other than highway-rail)	X-ING
Drive	DR*
East	E
Electric Vehicle	EV
Expressway	EXPWY*
Feet	FT
FM Radio	FM
Freeway	FRWY, FWY*
Friday	FRI
Hazardous Material	HAZMAT
High Occupancy Vehicle	HOV

Word Message	Standard Abbreviation
Highway	HWY*
Hospital	HOSP
Hour(s)	HR, HRS
Information	INFO
Inherently Low Emission Vehicle	ILEV
International	INTL
Interstate	(See Table 1A-2)
Junction / Intersection	JCT
Lane	(See Table 1A-2)
Liquid Propane Gas	LP-GAS
Maximum	MAX
Mile(s)	MI
Miles Per Hour	MPH
Minimum	MIN
Minute(s)	MIN
Monday	MON
Morning / Late Night	AM
Mount	MT
Mountain	MTN
National	NATL
North	N
Parkway	PKWY*
Pedestrian	PED
Place	PL*

Word Message	Standard Abbreviation
Pounds	LBS
Road	RD*
Saint	ST
Saturday	SAT
South	S
State, county, or other non-US or non-Interstate numbered route	(See Table 1A-2)
Street	ST*
Sunday	SUN
Telephone	PHONE
Temporary	TEMP
Terrace	TER*
Thursday	THURS
Thruway	THWY*
Tons of Weight	T
Trail	TR*
Tuesday	TUES
Turnpike	TPK*
Two-Way Intersection	2-WAY
US Numbered Route	US
Wednesday	WED
West	W

*This abbreviation shall not be used for any application other than the name of a roadway.

Variable Message Signs - VMS

A Variable Message Sign (VMS), also known as a Dynamic Message Sign (DMS), or Changeable Message Sign (CMS), is an electronic traffic sign often used on roadways to provide travelers with real-time information about specific events. The information displayed on the VMS can be changed as required, hence the name.

VMS are generally used for:

- 1. Traffic management and control:** They provide real-time traffic information to motorists, such as delays, accidents, road works, detours, or lane closures, to manage traffic flow more effectively and reduce congestion.
 - 2. Emergency alerts:** In cases of emergencies such as natural disasters, VMS can provide crucial, timely information to guide the public and direct traffic flow accordingly.
 - 3. Public transportation status updates:** VMS can be used to display times of next buses or trains in public transportation systems, helping passengers plan their journey better.
 - 4. Speed limit enforcement:** These signs can also display variable speed limits, adapting to current traffic or weather conditions, to enhance road safety.
 - 5. Advertising:** Some VMS are also used for promotional or advertising purposes, especially in commercial or event areas.
- In addition to road networks, VMS are also used in car parks, airports, railway stations, and various other environments where providing dynamic information can aid in managing and directing movement of people or vehicles. These signs can be controlled remotely and display messages in text or graphic format.

The intent of using a VMS is to inform drivers and other road users about unexpected changes, incidents, or conditions on the road ahead in time for them to make informed decisions. This can help to improve traffic flow, reduce incidents, and increase overall road safety.

A variable message sign (VMS) is mounted on a metal pole. The sign is rectangular with a black background and red LED text. The text is arranged in three lines: "ACCIDENT AHEAD", "30 MIN DELAY", and "USE NEXT OFFRAMP". The sign is positioned on a road with a grassy embankment and a clear sky in the background.

ACCIDENT AHEAD
30 MIN DELAY
USE NEXT OFFRAMP

Variable Message Signs - VMS

Signs & Markings II

Changeable Message Sign - Review



Advancing the Future of Public Safety

Knowledge Check: Multiple Choice

A changeable message sign is a traffic control device that is used to display one or more _____ messages.

- a. advertising
- b. alternative
- c. humorous
- d. social

Knowledge Check: Multiple Choice

A changeable message sign should NOT be used to display safety or transportation-related messages if doing so would adversely affect the _____ of the sign.

- a. color
- b. condition
- c. direction
- d. respect

Knowledge Check: Multiple Choice

The message on a changeable message sign should be designed to be legible from a MINIMUM distance of how many feet for normal daylight conditions?

- a. 400 FT
- b. 600 FT
- c. 800 FT
- d. 1000 FT

When deploying a changeable message sign, an IMSA signs & pavement markings technician II should verify the batteries are charged by checking the

- a. date of service
- b. fuel level
- c. software settings
- d. water levels

Knowledge Check: Multiple Choice

A changeable message sign on a roadway with a speed limit of 55 mph or higher should be visible from _____ under both day and night conditions

- a. a quarter of a mile
- b. half a mile
- c. three quarters of a mile
- d. one mile

Knowledge Check: Multiple Choice

A changeable message sign should be limited to no more than three lines, with no more than how many characters per line?

- a. 10
- b. 12
- c. 18
- d. 20

Signs & Markings II

Markings / Markings Standards



Advancing the Future of Public Safety



Markings Standards

Markings Standards

Section 3A.02 Standardization of Application

Standard:

- Each standard marking shall be used only to convey the meaning prescribed for that marking in this Manual. When used for applications not described in this Manual, markings shall conform in all respects to the principles and standards set forth in this Manual.

Guidance:

- Before any new highway, private road open to public travel (see definition in Section 1A.13), paved detour, or temporary route is opened to public travel, all necessary markings should be in place.

Standard:

- Markings that must be visible at night shall be retroreflective unless ambient illumination assures that the markings are adequately visible. **All markings on Interstate highways shall be retroreflective.**
- Markings that are **no longer applicable or Viable** for roadway conditions or restrictions and that might cause confusion for the road user shall be removed or obliterated to be unidentifiable as a marking as soon as practical.

Option:

- Until they can be removed or obliterated, markings may be temporarily masked with tape that is approximately the same color as the pavement.

Markings Standards - Colors

Standard:

- Markings shall be yellow, white, red, blue, or purple. The colors for markings shall conform to the standard highway colors. Black in conjunction with one of the colors mentioned in the first sentence of this paragraph shall be a usable color.
- 1. When used, white markings for longitudinal lines shall delineate:**
 - A. The separation of traffic flows in the same direction
 - B. The right-hand edge of the roadway
 - 2. When used, yellow markings for longitudinal lines shall delineate:**
 - A. The separation of traffic traveling in opposite directions
 - B. The left-hand edge of the roadways of divided highways and one-way streets or ramps
 - C. The separation of two-way left-turn lanes and reversible lanes from other lanes.
 - 3. When used, red raised pavement markers or delineators shall delineate:**
 - A. Truck escape ramps
 - B. One-way roadways, ramps, or travel lanes that shall not be entered or used in the direction from which the markers are visible.
 4. When used, blue markings shall supplement white markings for parking spaces for persons with disabilities.
 5. When used, purple markings shall supplement lane line or edge line markings for toll plaza approach lanes that are restricted to use only by vehicles with registered electronic toll collection accounts

Markings Standards - Stop Lines

stop lines shall consist of solid white lines extending across approach lanes to indicate the point at which the stop is intended or required to be made.

yield lines (see Figure 3B-16) shall consist of a row of solid white isosceles triangles pointing toward approaching vehicles extending across approach lanes to indicate the point at which the yield is intended or required to be made.

Guidance:

- **Stop lines should be 12 to 24 inches wide.**
- The individual triangles comprising the yield line should have a base of 12 to 24 inches wide and a height equal to 1.5 times the base. The space between the triangles should be 3 to 12 inches.
- **If used, stop and yield lines should be placed a minimum of 4 feet in advance of the nearest crosswalk line at controlled intersections,** except for yield lines at roundabouts as provided for in Section 3C.04 and at midblock crosswalks. In the absence of a marked crosswalk, the stop line or yield line should be placed at the desired stopping or yielding point, but should not be placed more than 30 feet or less than 4 feet from the nearest edge of the intersecting traveled way. 11 Stop lines at **midblock signalized Locations would be placed at least 40 feet in advance of the nearest signal.**

Signs & Markings II

Markings / Markings Standards
Review



Advancing the Future of Public Safety

After receiving the pavement markings layout plan, a tech should visit the site to

- a. Log layout measurements
- b. Photograph the layout
- c. Talk with the contractor
- d. Verify existing conditions

Knowledge Check: Multiple Choice

What is the MINIMUM distance that a stop bar should be installed before a crosswalk?

- a. 4 feet
- b. 6 feet
- c. 8 feet
- d. 10 feet

Knowledge Check: Multiple Choice

The project calls for parking stalls to be laid out and installed 20 feet from an intersection with a crosswalk. The engineer decided to change the intersection to be signal controlled. The parking stalls now need to be moved due to the new changes. How much farther back should the parking stalls be moved from the crosswalk?

- a. 5 FT
- b. 10 FT
- c. 15 FT
- d. 20 FT

Which of the following is the correct item to use to remove pavement markings?

- a. Grinder
- b. Putty Knife
- c. Solvent
- d. Water

What information is helpful when preparing to layout pavement markings?

- a. Annual average daily hours of light
- b. Annual average daily rain fall
- c. Annual average daily temperature
- d. Annual average daily traffic

Pavement markings **MUST be retroreflective on what type of roadway?**

- a. Airport Taxiways
- b. Chip seal roads
- c. Interstate highways
- d. Low-volume roadways

Knowledge Check: Multiple Choice

What tools are helpful to an Signs & pavement markings tech II in the laying out of pavement markings?

- a. Laser pointer, sharpie, and a handsaw
- b. Micrometer, screwdriver, and a calculator
 - a. Nails, chalk, and a hammer
 - b. Tape measure, string line, and paint

Knowledge Check: Multiple Choice

Which of the following materials is BEST to use for pre-marking a section of a roadway?

- a. Chalk
- b. Paint
- c. Stencils
- d. Thermoplastic

What is the BEST guide to use for determining a pavement layout?

- a. Approved site plans
- b. Contractor's scope of work
- c. Submitted roadway plans
- d. Survey results of road users

Knowledge Check: Multiple Choice

Which of the following are color markings that conform to the highway standard colors?

- a. Green, orange, black, pink
- b. Silver, olive, maroon, gray
- c. Teal, violet, turquoise, brown
- d. Yellow, white, red, blue, purple

The tools needed for documentation after striping has been done are

- a. A laptop, a smart phone (for pictures), and plans.
- b. A retroreflectivity gun, hand tools, and recording device
- c. A typewriter, pen, and paper
- d. Stencils, paint, and a spray gun

When having problems with any inconsistencies on a pavement marking project, the tech must notify

- a. City hall
- b. The project manager
- c. Public works
- d. The traffic management center

How does the IMSA signs & pavement markings tech II check striping for retroreflectivity after its been installed?

- a. Conduct a night survey
- b. Drive by after it has been installed
- c. Notify the police department
- d. Use a retroreflectivity gun

Knowledge Check: Multiple Choice

Besides paint, what other material can an IMSA signs & markings Tech use to stripe highways and streets?

- a. Plastic
- b. Rubber
- c. Stickers
- d. Thermoplastic

How wide is a standard stop bar?

- a. 6 to 8 inches wide
- b. 8 to 12 inches wide
- c. 10 to 16 inches wide
- d. 12 to 24 inches wide

When should pavement markings be updated?

- a. when they are no longer viable
- b. every 6 months
- c. annually
- d. never

What should every paint truck have on board?

- a. Air conditioning
- b. laser guidance system
- c. Rake
- d. Spill containment Kit

What tool is NOT used when measuring thermoplastic pavement markings?

- a. Protractor
- b. Reflectometer
- c. Tape Measure
- d. Thickness Gauge

Signs & Markings II

Working With Contractors



Advancing the Future of Public Safety

Working with Contractors

Working with traffic sign and markings contractors involves collaboration and coordination to ensure the effective installation, maintenance, and management of traffic signs and pavement markings. Here are some key considerations when working with such contractors:

- **Project Planning and Specifications:** Clearly define the project requirements and specifications for traffic signs and markings. Provide detailed plans, drawings, or documentation specifying the types of signs and markings needed, their locations, dimensions, colors, and any applicable standards or regulations. Ensure that the contractors have a clear understanding of the project scope.
- **Contractor Selection:** Select reputable contractors with experience and expertise in traffic sign and marking installations. Consider their track record, qualifications, certifications, and their ability to meet project deadlines. Obtain references and evaluate past projects to ensure the contractors have a history of delivering quality work.



Working with Contractors

- **Pre-Construction Meetings:** Conduct pre-construction meetings with the contractors to discuss project details, clarify expectations, and address any questions or concerns. Review the project plans, specifications, and scheduling requirements. Establish clear lines of communication and define roles and responsibilities for both parties.
- **Coordination and Communication:** Maintain open lines of communication with the contractors throughout the project. Regularly communicate project updates, changes, or any issues that may arise. Ensure that any modifications or variations from the original plans are properly documented and approved to avoid misunderstandings.

Working with Contractors

- **Quality Assurance and Inspection:** Establish a process for quality assurance and inspection of the work performed by the contractors. Conduct regular inspections to verify that the installed signs and markings meet the specified requirements and comply with applicable standards. Document any deficiencies and work with the contractors to rectify them promptly.
- **Compliance with Regulations and Standards:** Ensure that the contractors are familiar with and adhere to all relevant regulations, guidelines, and standards pertaining to traffic signs and markings. This includes compliance with local, state, or national transportation regulations, as well as standards such as the Manual on Uniform Traffic Control Devices (MUTCD).
- **Safety Considerations:** Emphasize the importance of safety during all aspects of the project. Ensure that the contractors follow proper safety protocols, use appropriate personal protective equipment (PPE), and adhere to traffic control measures to protect workers and road users during installation or maintenance activities.

Working with Contractors

- **Contract Management:** Maintain clear and well-defined contracts or agreements with the contractors. Clearly outline project deliverables, timelines, payment terms, and any other relevant contractual terms. Monitor progress and ensure that the contractors fulfill their obligations according to the agreed-upon terms.
- **Ongoing Maintenance and Management:** Establish a plan for ongoing maintenance and management of traffic signs and markings after installation. Discuss with the contractors the expected lifespan of the signs and markings and establish a maintenance schedule to ensure their visibility, legibility, and overall effectiveness over time.
- **Performance Evaluation:** Evaluate the performance of the contractors upon completion of the project. Assess their adherence to project requirements, quality of work, responsiveness, and ability to meet project objectives. Provide constructive feedback and share recommendations for improvement.

Inspecting A Contractors Work

Inspecting a markings contractor's work is of utmost importance for several reasons:

- **Quality Assurance:** Inspections ensure that the pavement markings meet the required quality standards. They help identify any deficiencies, errors, or deviations from specifications, allowing for timely corrections and ensuring that the markings effectively serve their intended purpose.
- **Safety:** Accurate and well-maintained pavement markings contribute to road safety. Inspections help identify safety hazards such as faded or worn-out markings, improper placement, or inconsistent dimensions. Timely detection and rectification of these issues can prevent accidents and improve overall road user safety.
- **Compliance with Regulations:** Pavement markings must comply with applicable regulations, standards, and guidelines. Inspections ensure that the markings meet these requirements, including factors such as line widths, reflectivity levels, color contrasts, and placement criteria. Compliance with regulations is vital for legal and liability reasons.

Inspecting A Contractors Work

Inspecting a markings contractor's work is of utmost importance for several reasons:

- **Quality Assurance:** Inspections ensure that the pavement markings meet the required quality standards. They help identify any deficiencies, errors, or deviations from specifications, allowing for timely corrections and ensuring that the markings effectively serve their intended purpose.
- **Safety:** Accurate and well-maintained pavement markings contribute to road safety. Inspections help identify safety hazards such as faded or worn-out markings, improper placement, or inconsistent dimensions. Timely detection and rectification of these issues can prevent accidents and improve overall road user safety.
- **Compliance with Regulations:** Pavement markings must comply with applicable regulations, standards, and guidelines. Inspections ensure that the markings meet these requirements, including factors such as line widths, reflectivity levels, color contrasts, and placement criteria. Compliance with regulations is vital for legal and liability reasons.



Signs & Markings II

Working With Contractors Review



Advancing the Future of Public Safety

Knowledge Check: Multiple Choice

A Technician is inspecting the installation of pavement markings. A mistake in the layout was discovered and requires a correction. Who should be notified?

- a. City hall
- b. Contractor performing the work
- c. Law enforcement office
- d. Street supervisor

Why does the IMSA signs & pavement markings technician II need to be able to read site plans?

- a. The plans are generic templates that can be used for multiple projects.
- b. The plans are legal document that cannot be revised
- c. The plans have all the necessary data to complete the project.
- d. The pans have the price list for material's

What PPE is needed on a job site when doing a final walk through?

- a. Concrete, screwdriver, impact gun
- b. Jack hammer, sledge hammer, air compressor
- c. Laptop, headphone, smartphone
- d. Steel toe boots, hard hat, vest

Knowledge Check: Multiple Choice

A technician is checking striping that was done by a contractor on a highway. What standard does the technician use to see if the striping was done correctly?

- a. AASHTO
- b. ATC Standards
- c. Contractor's guidelines
- d. MUTCD

What standards reference guide should be followed when reviewing site plans?

- a. AASHTO
- b. ANSI
- c. MUTCD
- d. OSHA

What should be done before any signs or pavement markings are installed in a new development?

- a. Check retroreflectivity
- b. Review plans
- c. Take pictures
- d. Visual inspection

Knowledge Check: Multiple Choice

An IMSA signs & pavement marking technician II is inspecting a new development. The color of the right-hand edge line of the roadway should be

- a. blue
- b. green
- c. white
- d. yellow

Knowledge Check: Multiple Choice

An IMSA signs & pavement markings technician II is inspecting pavement markings in a new development. To whom should the technician report installation errors?

- a. IMSA S&PM tech 1
- b. Mayor
- c. Police Chief
- d. Project Manager

Signs & Markings II

Sign Inspections



Advancing the Future of Public Safety

How weather affects signs

Traffic signs are subject to various environmental conditions, including weather, which can affect their effectiveness and longevity. The effects of weather on traffic signs can include:

- 1. Fading:** Extended exposure to the sun's UV rays can cause the colors on traffic signs to fade. Fading reduces the sign's visibility and its effectiveness. Signs with bright colors, like stop signs (red) or warning signs (yellow), tend to be more affected as any fading can decrease their ability to grab attention.
- 2. Wind Damage:** Strong winds, hurricanes, or tornadoes can cause physical damage to traffic signs. This could lead to the sign becoming dislodged from its post, bent, or even broken. Larger signs or those with a broad surface area can be more affected as they present more resistance to wind.
- 3. Snow and Ice:** In colder climates, snow and ice can cover signs, making them unreadable. The weight of accumulated ice or snow could potentially cause a sign to bend or fall.
- 4. Corrosion:** In coastal areas or regions with heavy snowfall (where de-icing salts are often used on roads), the metal components of traffic signs can corrode over time. Corrosion can weaken the sign post and fasteners, leading to potential failure.
- 5. Temperature Effects:** Extreme temperatures, both hot and cold, can affect the materials of traffic signs. In hot weather, signs can warp or buckle, while in cold temperatures, they may become brittle and more prone to cracking or breaking.

These are just a few reasons why a Sign Inspection Plan is important

Sign Inspections


Traffic sign inspections are a crucial part of maintaining a safe and efficient transportation system. They help ensure that all signs are in good condition, clearly visible, and providing accurate information. Inspections typically focus on several key aspects:

- 1. Visibility:** Signs should be easily visible to drivers. This includes both daytime and nighttime visibility. For instance, inspectors may use a retroreflectometer, a device that measures the level of retroreflectivity (how much light the sign reflects back to its source), to ensure that the sign still meets the required standards for nighttime visibility.
- 2. Physical Condition:** This includes checking for any physical damage to the sign, such as bends, dents, or cracks, as well as any damage to the post or mounting. Any graffiti or stickers that could obscure the sign's message would also be noted.
- 3. Position and Height:** The sign's height and position should be checked to ensure it's mounted at the correct height and angle, facing the oncoming traffic for maximum visibility.

Sign Inspections

- 4. Corrosion:** In coastal areas or regions with heavy snowfall (where de-icing salts are often used on roads), the metal components of traffic signs can corrode over time. Corrosion can weaken the sign post and fasteners, leading to potential failure.
- 5. Legibility:** Over time, a sign's message can fade or become obscured due to weather, UV radiation, or other factors. The sign's legibility should be checked to ensure drivers can easily read and understand the sign's message.
- 6. Compliance with Standards:** The sign should be checked for compliance with local and national standards regarding size, color, design, and reflectivity.
- 7. Surrounding Environment:** The surrounding environment should also be inspected to ensure that the sign is not obscured by things like overgrown vegetation, dirt, or other structures.

Sign Inspections - GPS



- Many departments have now started to use sign management systems to help manage this process. These systems use GPS and database technology to create a record of every sign, its installation date, condition, and date of last inspection. It helps automate the process and ensures that no sign is overlooked.

Sign Inspections

Inspections for traffic signs are crucial for maintaining roadway safety and ensuring signs meet local and national standards. Here are some common types of inspections:

- 1. Nighttime Inspections:** These inspections are conducted at night to evaluate the retroreflectivity of the sign, which is the ability of the sign to reflect light back to the source, making it visible in the dark. For this, a vehicle with headlights on is driven on the road to check if the signs are clearly visible and legible.
- 2. Daytime Inspections:** During the day, signs are inspected for general visibility, legibility, correct positioning, physical condition (checking for damage, rust, or wear), and if they are obscured by overgrown vegetation or other obstructions.
- 3. Scheduled Inspections:** Regularly scheduled inspections are conducted at predetermined intervals, which could be annually, biannually, or based on some other timeline. These inspections might include both daytime and nighttime checks.
- 4. In-Depth Inspections:** These could involve a detailed evaluation of each sign to assess its condition, including factors like sign sheeting (the material the sign face is made of), post integrity, and hardware (bolts, brackets, etc.). These are generally more time-consuming and might be conducted on a rotating schedule, with different sections of the roadway being inspected each time.

Nighttime Inspection

- These inspections are conducted at night to evaluate the retroreflectivity of the sign, which is the ability of the sign to reflect light back to the source, making it visible in the dark. For this, a vehicle with headlights on is driven on the road to check if the signs are clearly visible and legible.



Daytime Inspections

- During the day, signs are inspected for general visibility, legibility, correct positioning, physical condition (checking for damage, rust, or wear), and if they are obscured by overgrown vegetation or other obstructions.



Scheduled Inspections

- Regularly scheduled inspections are conducted at predetermined intervals, which could be annually, biannually, or based on some other timeline. These inspections might include both daytime and nighttime checks
- These could involve a detailed evaluation of each sign to assess its condition, including factors like sign sheeting (the material the sign face is made of), post integrity, and hardware (bolts, brackets, etc.). These are generally more time-consuming and might be conducted on a rotating schedule, with different sections of the roadway being inspected each time.



Common Tools for Sign Inspections

- **Retroreflectometer:** This device measures the retroreflective properties of the sign. It's used to ensure that the sign meets the minimum retroreflectivity levels set by standards like the Manual on Uniform Traffic Control Devices (MUTCD) in the United States.



Scheduled Inspections

Traffic sign retroreflectivity refers to the ability of a sign's surface to reflect light back to its source, such as a vehicle's headlights. It plays a crucial role in maintaining visibility and legibility of signs, especially during nighttime and low-light conditions. Table 2A-3 from the MUTCD is the Minimum Maintained Retroreflectivity levels. Retroreflectivity is one of the primary aspects of signs that determine if they require replacement.

Table 2A-3. Minimum Maintained Retroreflectivity Levels¹

Sign Color	Sheeting Type (ASTM D4956-04)				Additional Criteria
	Beaded Sheeting		Prismatic Sheeting		
	I	II	III	III, IV, VI, VII, VIII, IX, X	
White on Green	W*; G ≥ 7	W*; G ≥ 15	W*; G ≥ 25	W ≥ 250; G ≥ 25	Overhead
	W*; G ≥ 7	W ≥ 120; G ≥ 15			Post-mounted
Black on Yellow or Black on Orange	Y*; O*	Y ≥ 50; O ≥ 50			²
	Y*; O*	Y ≥ 75; O ≥ 75			³
White on Red	W ≥ 35; R ≥ 7				⁴
Black on White	W ≥ 50				–
¹ The minimum maintained retroreflectivity levels shown in this table are in units of cd/lx/m ² measured at an observation angle of 0.2° and an entrance angle of -4.0°.					
² For text and fine symbol signs measuring at least 48 inches and for all sizes of bold symbol signs					
³ For text and fine symbol signs measuring less than 48 inches					
⁴ Minimum sign contrast ratio ≥ 3:1 (white retroreflectivity ÷ red retroreflectivity)					
* This sheeting type shall not be used for this color for this application.					
Bold Symbol Signs					
<ul style="list-style-type: none"> • W1-1,2 – Turn and Curve • W1-3,4 – Reverse Turn and Curve • W1-5 – Winding Road • W1-6,7 – Large Arrow • W1-8 – Chevron • W1-10 – Intersection in Curve • W1-11 – Hairpin Curve • W1-15 – 270 Degree Loop • W2-1 – Cross Road • W2-2,3 – Side Road • W2-4,5 – T and Y Intersection • W2-6 – Circular Intersection • W2-7,8 – Double Side Roads 		<ul style="list-style-type: none"> • W3-1 – Stop Ahead • W3-2 – Yield Ahead • W3-3 – Signal Ahead • W4-1 – Merge • W4-2 – Lane Ends • W4-3 – Added Lane • W4-5 – Entering Roadway Merge • W4-6 – Entering Roadway Added Lane • W6-1,2 – Divided Highway Begins and Ends • W6-3 – Two-Way Traffic • W10-1,2,3,4,11,12 – Grade Crossing Advance Warning 		<ul style="list-style-type: none"> • W11-2 – Pedestrian Crossing • W11-3,4,16-22 – Large Animals • W11-5 – Farm Equipment • W11-6 – Snowmobile Crossing • W11-7 – Equestrian Crossing • W11-8 – Fire Station • W11-10 – Truck Crossing • W12-1 – Double Arrow • W16-5P,6P,7P – Pointing Arrow Plaques • W20-7 – Flagger • W21-1 – Worker 	
Fine Symbol Signs (symbol signs not listed as bold symbol signs)					
Special Cases					
<ul style="list-style-type: none"> • W3-1 – Stop Ahead: Red retroreflectivity ≥ 7 • W3-2 – Yield Ahead: Red retroreflectivity ≥ 7; White retroreflectivity ≥ 35 • W3-3 – Signal Ahead: Red retroreflectivity ≥ 7; Green retroreflectivity ≥ 7 • W3-5 – Speed Reduction: White retroreflectivity ≥ 50 • For non-diamond shaped signs, such as W14-3 (No Passing Zone), W4-4P (Cross Traffic Does Not Stop), or W13-1P,2,3,6,7 (Speed Advisory Plaques), use the largest sign dimension to determine the proper minimum retroreflectivity level. 					

Reasons for Inspection

A sign inspection program is crucial for a few key reasons:

- **Safety:** Traffic signs play a vital role in road safety, providing necessary information and guidance to drivers and pedestrians. Faded, damaged, or obscured signs can lead to confusion or misinterpretation, potentially causing accidents. When a tech is sent out to observe a line of sight of a sign, they should be ready to remove the obstruction like the image shown.
- **Legal Compliance:** Regular inspections ensure that all signs are in compliance with local and national regulations, which may change over time.
- **Maintenance and Budget Planning:** Regular inspections allow for identification of signs that need maintenance or replacement, helping to budget and plan for these expenses effectively.





Reasons for Inspection

- **Aesthetics and Community Image:** Well-maintained signs contribute to a positive community image and show attention to public safety.
- As for the frequency of inspections, it can depend on a number of factors including local regulations, the type of sign, the environment, and the amount of wear and tear they typically experience. However, the Manual on Uniform Traffic Control Devices (MUTCD) suggests an inspection at least once a year for regulatory and warning signs, and once every two years for guide signs.

Signs & Markings II

Sign Inspection Review



Advancing the Future of Public Safety

Knowledge Check: Multiple Choice

An IMSA signs & pavement technician II discovers an incorrectly installed sign. Who should the Tech contact?

- a. City Manager
- b. Co-Worker
- c. Police Department
- d. Project Manager

Knowledge Check: Multiple Choice

When tasked with a work order to check the line of sight at an intersection, a Tech should be prepared to _____ as needed?

- a. Call in locates
- b. Post a warning notice
- c. Remove the obstruction(S)
- d. Remove the sign

Knowledge Check: Multiple Choice

What standard should the IMSA signs & pavement markings tech II use to inspect all work performed?

- a. AASHTO
- b. Local building codes
- c. MUTCD
- d. NEC

What does an IMSA signs & pavement markings tech II check to determine if a sign needs to be replaced?

- a. Letter height
- b. Retroreflectivity
- c. Shape
- d. Sheeting

Signs & Markings II

Asset Management / Inventory



Advancing the Future of Public Safety

Asset Management

Asset management plays a crucial role in the effective management and maintenance of traffic signs. Here are some key reasons why asset management is important in this context:

- **Inventory Management:** Asset management helps in maintaining an accurate inventory of traffic signs. It includes recording details such as the type, location, condition, and age of each sign. This information is vital for planning maintenance, replacement, and upgrades.
- **Maintenance Planning:** By monitoring the condition of traffic signs and their components, asset management allows transportation agencies to schedule regular maintenance activities effectively. It ensures that signs are kept in proper working order, legible, and visible to road users.
- **Cost Efficiency:** Effective asset management minimizes unnecessary costs associated with traffic sign maintenance. It enables agencies to prioritize repairs and replacements based on the signs' condition, ensuring that resources are allocated efficiently.

Asset Management

- **Compliance and Safety:** Traffic signs are essential for conveying information, regulating traffic, and ensuring road user safety. Asset management ensures that signs meet regulatory requirements, are visible, and provide accurate information to drivers. Regular inspections and maintenance help identify signs that may be damaged, faded, or obscured, thereby mitigating potential safety risks.
- **Planning and Decision Making:** Accurate data collected through asset management allows transportation agencies to make informed decisions regarding sign placement, upgrades, and replacements. This data can be used to identify areas with inadequate signage, areas prone to vandalism or theft, or signs that require specific attention due to changing traffic conditions.
- **Performance Monitoring:** Asset management provides a framework for monitoring the performance and effectiveness of traffic signs. It enables agencies to track key performance indicators, such as sign lifespan, maintenance costs, compliance rates, and response times for repairs. This information assists in evaluating the overall efficiency of sign management practices and identifying areas for improvement.

Sign Management Software

- Some jurisdictions use sign management software systems, which help in tracking the condition, maintenance, and replacement of signs. These systems can schedule inspections, store photos and conditions of the signs, and help in planning budgets for sign replacement or repair.

Signs & Markings II

Asset Management / Inventory Review



Advancing the Future of Public Safety

Asset tracking involves which of the following?

- a. Billing
- b. Counting
- c. Locating
- d. Purchasing

What is the BEST way to keep track of the assets in the system?

- a. CCTV
- b. GIS
- c. GPS
- d. Spreadsheets

What information should be included in an installed sign inventory?

- a. brightness
- b. clarity
- c. condition
- d. letter spacing

Signs & Markings II

Temporary Traffic Control



Advancing the Future of Public Safety

A concurrent objective of the temporary traffic control is the efficient construction and maintenance of the highway and the efficient

- a. Documentation of traffic incidents
- b. Recording of traffic incidents
- c. Reporting of traffic incidents
- d. Resolution of traffic incidents

Knowledge Check: Multiple Choice

Prior to installation, where should a Tech locate signs and other devices so they can be moved quickly into position?

- a. In the ditch
- b. In the roadway
- a. On Shoulder of the road
- b. On the truck

Knowledge Check: Multiple Choice

In Preparation of setting up a work zone, a technician should _____ all devices to be used ensuring they are clean and in good working order.

- a. Deliver
- b. Inventory
- a. Photograph
 - b. Tag

Knowledge Check: Multiple Choice

When erratic motorists movements or behaviors are observed, threatening the safety of the public and works. Who should you contact?

- A. Contact city hall
- b. Lengthen the work zone
- c. Request police presence
- D. Shorten the work zone

Knowledge Check: Multiple Choice

When adding a left-turn lane on a collector type roadway, what is a good deciding factor if a work zone is necessary?

- a. Equipment available to crews
- b. Type of neighborhood
- c. Type of vehicular traffic
- d. Volume and speed of traffic

Knowledge Check: Multiple Choice

Once a device is installed, the tech should drive the area to specifically_____ the device that was installed.

- a. Clean
- b. Cover
- c. Inspect
- d. Sync